expander control
(controlled from top of club)

outer
shaft

internal
tube

expander

expander

inner
shaft

expander control
(controlled from bottom
of club)

CLAIM 2   CLAIM 3